



## "COIL" BINDING MACHINES

																	COIL MACHINES	COMB	WIRE	
Manufacturer	Sheet Format	Punch Capacity (# Sheets)	Binding Capacity	Punching Length	Pitch	Reverse Switch/Jam Release	Open Punch Throat	Adjustable Side Margin	Adjustable Depth Margin	Die Disengaging Pins	Warranty (# Years)	Machine Construction	U-shaped Alignment Channel	Electric Inserter	Coil Crimper Included	Diameter Selector	Table/Ruler/Guide	Wire Selector	Weight (Lbs)	
<b>COIL MACHINES (MANUAL PUNCHING)</b>																				
RubiCoil	AKILES	Letter ONLY	10	Up to 2"	11"(43 Dies)	4:1		•			1	Metal					N/A	N/A	16	
CoilMac-M	AKILES	ALL formats	28***	Up to 2"	13" (53 Dies)	4:1	•	•	•	• (5)	1	Metal				•	N/A	N/A	35	
CoilMac-M Plus	AKILES	ALL formats	28***	Up to 2"	13" (54 Dies)	4:1 Oval	•	•	•	• (54)	1	Metal				•	N/A	N/A	35	
CoilMac-ER	AKILES	ALL formats	28***	Up to 2" *	13" (53 Dies)	4:1	•	•	•	• (5)	1	Metal	• (4)**	•	•	•	N/A	N/A	38	
CoilMac-ER Plus	AKILES	ALL formats	28***	Up to 2" *	13" (54 Dies)	4:1 Oval	•	•	•	• (54)	1	Metal	• (4)**	•	•	•	N/A	N/A	38	
CoilMac-ECI	AKILES	ALL formats	28***	Up to 2" *	13" (53 Dies)	4:1	•	•	•	• (5)	1	Metal	• (11)**	•	•	•	N/A	N/A	59	
CoilMac-ECI Plus	AKILES	ALL formats	28***	Up to 2" *	13" (54 Dies)	4:1 Oval	•	•	•	• (54)	1	Metal	• (11)**	•	•	•	N/A	N/A	59	
CC-320 (Comb + Coil Combo)	SIRCLE	Letter ONLY	20 (Comb) 12 (Coil)	2"(Comb) 7/8" (Coil)	11"	Coil 4:1		•			1	ABS	• (11)**			•		N/A	32	
ADM-C41 (Comb + Coil Combo)	AKILES	ALL formats	20	Up to 2"	Comb 14" Coil 13"	Coil 4:1	•	•	•	24Comb 5 Coil	1	Metal	•	Optl.	•	•	•	N/A	64	
ADM-431 (Coil + Wire Combo)	AKILES	ALL formats	20	2"(Coil) 9/16" (Wire)	Coil 13" Wire 14"	Coil 4:1 Wire 3:1	•	•	•	5 Coil 40 Wire	1	Metal	•	Optl.	•	•	N/A	•	53	
ADM-421 (Coil + Wire Combo)	AKILES	ALL formats	20	2"(Coil) 1.25" (Wire)	Coil 13" Wire 14"	Coil 4:1 Wire 2:1	•	•	•	5 Coil 27 Wire	1	Metal	•	Optl.	•	•	N/A	•	53	
<b>COIL MACHINES (ELECTRIC PUNCHING)</b>																				
CoilMac-EPI	AKILES	ALL formats	28***	Up to 2" *	13" (53 Dies)	4:1	•	•	•	• (5)	1	Metal	•	• (11)**	•	•	•	N/A	N/A	75
CoilMac-EPI Plus	AKILES	ALL formats	28***	Up to 2" *	13" (54 Dies)	4:1 Oval	•	•	•	• (54)	1	Metal	•	• (11)**	•	•	•	N/A	N/A	75
VersaMac <i>Interchangeable Die Machine</i>	AKILES	ALL formats	up to 55	N/A	14"	All	•	•	•	•	1	Metal	N/A	Optl.	Optl.	N/A	N/A	N/A	121	
VersaMac Includes <b>ONE</b> Standard Punch Die Set of your choice ( <b>Choose: Coil 4:1, Wire 3:1, Wire 2:1, Comb, 3 Hole</b> ). Additional Punch Dies available (See website).																				
VersaBind-E <i>Interchangeable Die Machine</i>	TAMERICA	ALL formats	up to 20	N/A	14"	All		•	•	•	All	1	Metal	Y	N/A	N/A	N/A	N/A	N/A	102
VersaBind Includes <b>FOUR</b> Standard Punch Dies ( <b>Coil 4:1, Wire 3:1, Wire 2:1, &amp; Comb</b> ).																				
<b>REMARKS</b>																				
* You can bind up to 2" manually, however 7/8" max is recommended if using electric inserter.																				
** ( # ) refers to length in inches allowed through at one time. The 11" models have an additional roller for added support.																				
*** To punch thicker materials (such as hardboard), simply remove the punch throat shield & proceed to punch.																				



## **DEFINITIONS**

**Die Disengaging Pins**- Pins that disengage are pins that you can "turn off". When you pull the pin out, that particular pin will not punch a hole in your document when you pull the handle down. This allows you to control where your holes are punched in your document.

**Comb table/ruler/guide**- This is a guide on the machine that you can put your stack of papers up to. The guide will let you know what size coil you should use based on how many papers you need to bind into one booklet.

**Punching Length**- This is the length of paper and how many holes that the machine can punch at one time.

**Open Punch Throat**- This is an open side to the machine where you put your papers in to punch. If the machine has an open throat, you can punch documents that are longer than standard 11.5" length.

**Adjustable Side Margin**- This tool allows you to move a guide along the side for proper paper alignment and more accurate hole punching on each end of your document.

**Adjustable Depth Margin**- This tool allows you to move a guide along the top for proper paper alignment and more accurate hole punching on the long side of your document.

**Continuous Binding Control**- Prevents over-opening of combs.

**Pitch**- The pitch is how many rings there are per inch. For example, the coils have 4 rings per every inch of binding (4:1 Pitch).

**U-Shaped Alignment Channel**- An essential tool for books thicker than 1/2". Put your paper in this channel and it creates the same curved form as your coil.